

PREPARE	
Fuel	LOAD
Payload	LOAD
Parking brake	SET
Battery	ON
GPU	CONNECT
External power	ON
Galley power	ON
Navigation light	ON
Logo light	ON
Ground flood lights	ON
Beacon light	OFF
Nose light	OFF
Landing lights	OFF
High intensity lights	OFF
Dome	AS REQ
Instrument lights	AS REQ
Emergency lights	ARM

SYSTEMS TEST	
AUX HYD pump	ON
HYD TRANS	ON
Hyd sd display	CHECK
AUX HYD pump	OFF
HYD TRANS	OFF
EGPWS mode	TEST
Emergency power	ARM
Wing ice detection	TEST
Fuel system	TEST
Gear handle warning	TEST
Stabilizer trim	TEST
TCAS	TEST
Oxygen	TEST
Voice recorder	TEST
Cargo smoke	TEST

PRE FLIGHT	
Isolation valve	OPEN
PACKS	ON
Windshield anti-ice	ON
Windshield anti-fog	ON
Wing anti-ice	AS NEEDED
Tail anti-ice	AS NEEDED
No smoking sign	ON
Seat belt sign	ON
Altimeter	SET
IRS switches	NAV
Fire warning	TEST
Takeoff warning	TEST
Weather Radar	TEST
Fuel pumps	OFF
Radios	SET
Transponder	SET

MCDU	
INIT page 1	ENTER
Initialize IRS	PUSH
F-PLN page	ENTER
INIT page 2	ENTER
TO/APPR page	ENTER

PUSHBACK	
R AFT pump	ON
APU MASTER	START
APU GEN	ON
APU AIR	ON
External power and air	DISCONNECT
Wheel chocks and cones	DISCONNECT
HYD pumps	ON
AUX HYD pump	ON
HYD TRANS	ON
All fuel pumps	ON
TCAS mode	ALT ON
Ice protection	CHECKED
Beacon	ON
Parking brake	OFF
PACKS	OFF
L ENG START	PULL
L ENG FUEL VALVE	ON
R ENG START	PULL
R ENG FUEL VALVE	ON

AFTER START	
L ENG ICE protection	AS NEEDED
R ENG ICE protection	AS NEEDED
PACKS	ON
ISOL valve	AUTO
APU AIR	OFF
ENG generators	ON

BEFORE TAXI	
FLAPS	SET
SPOILERS	ARM
STAB trim	SET
Brake temp	CHECKED
Flight controls	CHECKED
EAD green box	CHECKED
Nose lights	TAXI

BEFORE TAKEOFF	
TCAS mode	TA/RA
Landing lights	ON
Nose lights	LAND
High intensity lights	LAND
Flight attendant	CALL

AFTER TAKEOFF	
GEAR	UP
FLAPS	UP
AUX HYD pump	OFF
HYD TRANS	OFF
SPOILERS	DISARM
AUTOFLIGHT	ON
APU GEN	OFF
APU AIR	OFF

CLIMB	
Landing lights above 10.000 ft	OFF
Seat belt sign	OFF
Altimeters above transition alt	STANDARD
Fuel pumps and quantity	CHECKED

DESCENT	
Altimeters below transition level	SET
Minimums	SET
TO/APPR page	SET
Landing lights below 10.000 ft	ON
Seat belt sign	ON
AUX HYD pump	ON
HYD TRANS	ON
Anti-ice	CHECKED

APPROACH	
Verify navigation and instruments	CHECKED
Approach/landing mode	ON
FLAPS	SET
GEAR	DOWN
SPOILERS	ARMED
Altimeters	CHECKED

AFTER LANDING	
SPOILERS	RETRACTED
FLAPS	UP
Landing lights	OFF
High intensity lights	OFF
Nose lights	TAXI
Weather radar	OFF
TCAS mode	ALT ON
APU MASTER	START
APU GEN	ON
APU AIR	ON

SHUTDOWN	
Parking brake	SET
GPU	CONNECT
ENGINES	OFF
Beacon	OFF
Nose lights	OFF
Ground flood lights	OFF
AUX HYD pump	OFF
HYD TRANS	OFF
PACKS	OFF
Fuel pumps	OFF
Seat belt signs	OFF
IRS	OFF
Galley power	OFF
Emergency lights	OFF
Power	OFF
Battery	OFF